WORKSMAN PERSONAL ACTIVITY VEHICLE ASSEMBLY INSTRUCTIONS AND PARTS LIST

Worksman Trading Corp - 94-15 100th Street - Ozone Park, NY 11416 - (888) 3-WHEELER or 718 322 2000 – www.worksman.com Parts list PAV3-04

PAV3, PAV3-3CB



Worksman PAV3TM- A Tricycle Revolution

Congratulations! You have purchased an American Made Worksman Personal Activity Vehicle™ Comfort Tricycle. The PAV3™ is one of the most unique adult tricycles in the world. It combines comfort with durability, a true unique combination. We utilize the components and technology used on our world famous Worksman Industrial Cycles on the Personal Activity Vehicle.

Before assembly and riding, make certain to read this manual and any other literature provided thoroughly. Always follow the rules of

safe riding. Always keep your PAV3™ Tricycle in tip-top shape by replacing worn parts as needed with Genuine Worksman Cycles Parts. (Do not use generic bicycle parts.) With simple maintenance, your Worksman Tricycle will perform reliably day after day, year after year, decade after decade.

Your Personal Activity Vehicle™ Tricycle has been hand-made in the USA by our American craftspeople. Our reputation rides along with you, so your ultimate satisfaction is our goal.

Worksman PAV3™ Parts List PAV3-04

3 Speed Cable and Trigger for 404M

Frame, Fork and Related Parts			
Part #	Description	Part #	<u>Description</u>
72PAV	PAV3 Frame Only- Specify color		
5020HD	Fork-Color Black	5020HD-SP	Fork (other color- please specify
48	Head Set Cups (pair)	49	Headset Bearings (pair)
50A	Headset Complete (48,49,52,53,54)	51	Bottom Cone (presses on Fork)
52	Top Adjusting Cone (threaded)	53	Key Washer
54	Fork Top Lock nut	55PAV	Tiller Handlebar
55U	Stem for Handlebar	55Y	Foam Handlebar Grips (set)
3928PAV	Basket frame support	60STR	Drum Brake Fork Strap
Front Wheel	and Related Parts		
Part #	Description	Part #	Description
7720A	Front Wheel 20" w/Drum Brake w/o tire	7720	Front Wheel20" w/Drum Brake w/air tire
L900	Drum Brake-Hub Only	L709	Front Axle Set for Drum Brake
L752R	Brake Lever w/ Parking Lock	F817	Bearings-Loose 11 balls
F719-PAV	Front Drum Brake Cable and Casing (53")	L725	Drum Brake Plate Kit (Internal parts kit
	(Includes Adjusting Barrel and Anchor Bolt)		-Shoes, Plate, Lever and Cam)
F769	Anchor Bolt Assembly for F719-PAV Cable	F770	Adjusting Barrel for F719-PAV Cable
	nd Related Parts		
Part #	<u>Description</u>	Part #	<u>Description</u>
102	Key Washer	105	Adjusting Cone (threaded)
106	Stationary Cone (presses onto axle)	109	Dust Washer
113	Locknut (Left Hand Thread - Free Wheel Side)	146	Wheel Bearings (pair)
64M	Woodruff Key	59M	Locknut (Drive Side)
132		M13966	Rear Axle
69	Fixed Drive Sprocket	63B	Key (Fits in axle slot between sprocket & axle.)
63C	Set screw for 69	M13975	Side Bearing with Plate (each)
M13974	Center Axle Support Bearing	301M	Coaster Brake w/ Dual Sprockets
404M	3 Speed Coaster Brake w/dual Sprockets	SS721	Coaster Brake Internal Parts Kit (301M)



SS13-1

Crank and Crank Parts (Pedal Section) and Chains

Part #	<u>Description</u>	Part #	<u>Description</u>
1265	Crank Parts (1266,1268,1269,1271,1272,1273,1274)	1265BMXS	Deluxe Sealed Crank Set (Upgrade)
1266	Crank Bearings (pair)	1267F	Complete Crank Set with 32 T Sprocket
1267H	Complete Crank Set w/ 28 T Sprocket	7217	Pedal Set (Pair)
1268	Cups for crank housing (pair)	1269	Stationary washer (inside)
1271	Key Washer- Outside	1271	Key Washer- Outside
1272	Adjusting Cone (threaded)-Outside	1273	Stationary Cone- Inside
1274	Crank Locknut	1275	Crank-forged- 6.5"
1380F*	Sprocket 32Tooth	1380H*	Sprocket 28 Tooth
4910A	Chainguard	4914A	Chain Connecting Link (1/2x3/16")
4914SBST	Long Chain (PAV3-3CB, 163 links, 28T)	4914SB	Long Chain (PAV3, 165 links, 32T)
4914XX	Short Chain (All PAV3s, 37links)	4915	Chain Adjuster (for Coaster Brake)
* Note- The DAY	/3 comes standard with a 32T front enrocket. The DAN	/3-3CB compe eta	ndard with a 28T front enrocket. The

^{*} Note- The PAV3 comes standard with a 32T front sprocket. The PAV3-3CB comes standard with a 28T front sprocket. The 1265BMXS is a heavier duty upgrade for crank parts.

Seat, Fenders, Baskets and Cabinets

Part #	<u>Description</u>	Part #	<u>Description</u>
8220	Front Fender	4902	Side Fender (L or R)
M13994P	Side Fender Brace (L or R)	95	"L" Bracket-attach Front Fender to Fork
4905	Bolt set for attaching 4902 to top of M13996	4907A	Bolt Set to attach 8220 to Fork
4906	Bolt Set for bottom of M13996	MSF24	Complete Side Fender Kit w/ Braces
42	Rear Basket 18"x13"x6"	3928PAV	Rear Basket Frame
3927PAV	Rear Cabinet 22"x15"x8" (optional)	7912PAV	High Back Seat
7912AHB	Swivel Down Armrest Set (optional)	791P	Canopy Roof Set Complete
791PAV-BLK	Replacement Vinyl for Canopy - Black	4909SB	"T" Tightening Bolt for Seat
5927BB	Basket Strap- to mount to frame		

NOTE- PERSONAL ACTIVITY VEHICLES COME WITH A FRONT FENDER AS STANDARD EQUIPMENT. THE SIDE FENDER SET MAY BE ADDED AS AN OPTION BY ORDERING PART # MSF24 SHOWN BELOW. CARRY ADDITIONAL SUPPLIES WITH THE OPTIONAL HEAVY HAULER TRAILER.







Optional Rear Fender Kit

Wheels and Tires

Part # 7720A 78A M14038A	<u>Description</u> Front Wheel 20" w/Drum Brake w/o Tire Free Side 24" Wheel (left) w/o Tire Drive Side 24" Wheel (right) w/o Tire	<u>Part #</u> 7720 78 M14038	Description Front Wheel 20"w/Drum Brake w/Air Tire Free Side 24" Wheel (left) w/ Air Tire Drive Side 24" Wheel (right) w/ Air Tire
4922E 4922EKV 4922EWSW 4923E 6023B	Tire- 24x2.125 WTC Sup-r-Tire (standard) Tire- 24x2.125 WTC <u>KEVLAR</u> Sup-r-Tire Tire- 24x2.125 Sup-r-Tire-White Wall Tube- 24x2.125 (standard) Tube- Thorn Resistant 24x2.125	4922 4922KV 4299WSW 4923 6023	Tire- 20x2.125 WTC Sup-r-Tire Tire- 20x2.125 WTC KEVLAR Sup-r-Tire Tire- 20x2.125 Sup-r-Tire-White Wall Tube- 20x2.125 (standard) Tube- Thorn Resistant 20x2.125
1017B 1016C 1014C 101	Rim Strip 24" Rim- 24" (no spokes-outer rim only) Spoke for Side Wheel (11G - 9 9/16") Hub for Free Side Wheel	1017A 1015 1014E 3980M	Rim Strip 20" Rim- 20" (no spokes-outer rim only) Spoke for Front Wheel (11G - 7 3/16") Hub for Drive Side Wheel

NOTE- WORKSMAN PAV3 PERSONAL ACTIVITY VEHICLES COME STANDARD WITH WTC SUP-R-TIRES, WHICH ARE OUTSTANDING AND DURABLE. KEVLAR TIRES ARE BELTED AIR TIRES AND THORN RESISTANT TUBES ARE MEANT TO REDUCE THE OCCURRENCE OF FLAT TIRES. SPOKES SOLD IN BAGS OF 100 AND INCLUDE NIPPLES

Part #'s and specifications subject to change without notice as we are constantly seeking ways to improve our products.



Safety and Comfort Accessories

0 0 1 0 1 0 1 1 0 1			
Part #	Description	Part #	<u>Description</u>
3979	Ding Dong Chime Bell	303	Squeeze Bulb Horn
3973	Mega-Horn- Battery Operated- LOUD	201	Cable and Lock (set)
5848	Bar End Mirror	5030T	Reflector Set with Mounting Hardware
3961	Cup Holder – Frame Mounted	3978	Safety Flag on Pole
3975	Generator Light Set	P19	Bicycle Helmet
101710	Flashing Strobe Slight (Clear Lens)	101714	Flashing Strobe Light (Red Lens)
1006	Air Pump for Tire Inflation (Manual)	1000	Spoke Tightening Tool
2000	Chain Rivet Remover Tool	1265TW	Crank Cone Wrench
1001	Pedal Wrench	TRAILER	Heavy Hauler Trailer
791PAV	Canopy Roof Set	7217-41038	Weighted Platform Pedals with Straps
7217-41197	Pedals with Velcro Straps	SEATBELT	Seat Belt – Lap Type
ENG-PAV	Electric Drive System*	PSCUP	Cup Holder Deluxe - Armrest Mounted

^{*} Electric Drive Systems are subject to state and local approvals. The Purchaser assumes responsibility for meeting ordinances. Subject to availability.








Worksman Team Dual Tricycle


Eagle Lite Trike



132 Axle Parts Set



Exploded view of L900



1265 Crank Parts Set with 1275 Crank



M13966 Axle w/301M Coaster Brake, 69 Sprocket and 4914XX Chain



M13975 Axle Bearing w/Plate

ASSEMBLY INSTRUCTIONS FOR THE WORKSMAN PERSONAL ACTIVITY VEHICLE™ TRICYCLE:

Your Worksman PAV3™ Industrial Tricycle has been hand made by American craftspeople at our Ozone Park, New York City factory. We take great pride in each and every Worksman Cycle that we manufacture and appreciate your support. Please read this manual carefully prior to performing the simple finishing adjustments and prior to riding. Keep these instructions, as our parts list is contained within this document which you will need for future reference. Carefully remove the tricycle from the carton. You will notice the tricycle is pre-assembled at the factory. Some finishing assembly / adjustments required.

ADJUSTING THE HIGH BACK CAPTAIN'S SEAT:

Your PAV3 Tricycle comes with a thickly padded captain's seat. Simply position the seat on the sliding seat track, insert the large round washer onto the "T" Tightening Bolt, and thread the "T" bolt into the bottom of the seat. Slide the seat to a comfortable position where leg is ever so slightly bent at the knee when reaching for the pedal in its furthest position. Tighten the bolt so seat is secure and no longer slides across the track. Remember to always check tightness of seat before riding. If you ordered the swivel down armrests, once seated, rotate armrests to down position.


ADJUST HANDLEBAR:

Your Personal Activity Vehicle comes with a unique steering tiller. This tiller can be positioned for your own riding preference. The stem is not tightened at the factory so you can set it where you desire by simple lifting the tiller to a comfortable position and tightening the stem using a #5 Allen key. Make certain the stem is tight and the tiller remains in place even while exerting downward pressure.

MAINTENANCE TIPS AND NOTES:

- Always inspect your Worksman Cycle to insure that that all nuts, bolts, screws and hardware are tight and that no parts are worn or damaged. Do not attempt to straighten bent forks or frames.
- Lubricate chain every six months or as needed with light oil. Replace sprockets when teeth become worn, bent or broken. Keep chain adjusted so there is no more than 3/8" slack. Note: we make the chains tight at the factory, as we do know they will stretch during the break-in period.
- Lubricate crank parts as needed and replace pedals when the surface is worn of if pedal axle becomes "tight" or frozen.





<u>Drum Brake</u>: Your Worksman PAV3 Tricycle is equipped with an automotive type front drum brake. This brake is ideal for slowing your vehicle smoothly and reliably. It is engaged by squeezing the hand lever on the handlebar. To use "Park" feature, when cycle is completely stopped, squeeze hand lever and push in parking plunger button on lever. To disengage, simply squeeze lever until parking plunger button releases.

Drum Brakes are pre-adjusted at the factory. Readjust the cable tension as necessary using the adjusting barrel so that wheel spins freely and stops when brake is applied. Always replace worn brake cables (F719-PAV) and damaged hand levers. Internal parts are available for your Drum Brake (L725 parts kits and L709 axle set).

<u>Coaster Brake:</u> Foot activated coaster brakes are easy to use and reliable. To activate this internal brake, reverse the pedaling motion until the brake engages. To avoid skidding and maintain control, apply care when braking. This is especially true on wet surfaces. Apply brakes gently, gradually increasing pedal back pressure. Replace coaster brakes when they become worn.

Check chain tension regularly. Models that are ordered with 3 Speed coaster brakes, the operation is the same,. Simply select the gear you wish to ride in. First gear is for easier starts and low speed riding. As you changed to gear 2 and 3 you will note that pedaling effort increases as does distance traveled with each turn of the crank.

<u>Tires:</u> Always check for worn or damaged tires. The Worksman Sup-r-tires are heavy duty. We recommend 40PSI as proper level of inflation. Replace tires that are worn or cut immediately. Replace tubes that show leaks.

RULES FOR SAFE RIDING AND RESPONSIBLE OPERATION: Carefully read this manual before operating the cycle.

- It is the responsibility of the assembler to properly install all parts included and to inspect the cycle prior to riding to insure proper operation.
- Operator is responsible for required maintenance to keep the cycle in good operation condition
- Observe all traffic regulations in the operating environment (stop signs, etc.) Keep to the right and in a straight line. Ride in single file.
- Do not ride outdoors, at night. Have appropriate signaling device as needed. (We recommend the 3973 Mega Horn)
- Give Pedestrians the Right of Way. Always look around you to understand the riding environment and hazards.
- Do not carry passengers. Check brakes prior to riding
- Slow down when approaching turns or intersections. Tricycles are meant for slow pace rides, not for racing.
- Use proper hand signals when turning or stopping. Recommended Safety Options: Approved helmet, audible warning device.
- · Never ride the cycle if there are known repairs required. Do not exceed the recommended weight capacity of the cycle
- Do not stack cargo too high in basket and always secure cargo with appropriate tie down straps.
- Wipe surface of cycle clean and dry when exposed to corrosive substances or environment.
- Operate Cycle at slow speeds, particularly in high traffic areas
- Operators of cycles should be in good physical condition. Ride at your own risk.
- · Wear proper riding attire. Check shoelaces prior to riding so they do not become engaged in the chain and sprocket.
- Ride only on smooth, paved surfaces. Do not use off road. Do not ride on steep grades...designed for relatively flat roads.
- Do not operate a tricycle on steep grades. They are designed for relatively level, paved surfaces only.
- · Always replace worn parts with genuine Worksman Cycle Repair Parts. Keep a maintenance log for your records.
- Always keep both hands on the handlebars. Tricycles have a tendency to pull slightly to one side.
- If motorized, buyer responsible for meeting local laws relating to motorized vehicles and viability of operation.

LIMITED WARRANTY:

THIS CYCLE IS WARRANTED AGAINST FAULTY PARTS UNER THE FOLLOWING CONDITIONS: THIS WARRANTY DOES NOT COVER ANY FAILURE DUE TO ACCIDENT, ABUSE, MISUSE, NEGLECT OR AS THE RESULT OF NORMAL WEAR AND TEAR, OR IMPROPER ASSEMBLY. THE ENTIRE FRAME INCLUDING ALL WELDED JOINTS IS WARRANTED TO BE FREE FROM DEFECTS AND MATERIAL FOR ONE YEAR WHILE IN POSSESSION OF THE ORIGINAL PURCHASER. ALL OTHER PARTS ON THIS CYCLE EXCEPT TIRES AND TUBES IS WARRANTED FOR NINETY DAYS FROM THE DATE OF PURCHASE. REPAIR AND REPLACEMENT OF THESE PARTS IS TO BE ACCORDING THE WORKSMAN CYCLES PARTS AND SERVICE PROCEDURES AND MUST BE HANDLED DIRECTLY THROUGH THE SOURCE WHERE THE CYCLE WAS PURCHASED. IF UPON EXAMINATION OF THE PARTS IN QUESTION, THE WORKSMAN CYCLE PARTS IN GUESTION, THE WORKSMAN CYCLE PETERMINES THAT IT IS DEFECTIVE, EAITHER REPAIR OR REPLACEMENT WILL BE MADE AT NO COST EXCEPT THE COST OF TRANSPORTATION AND LABOR CHARGES (IF ANY). UNAUTHORIZED REPAIRS OR REPLACEMENT AUTOMATICALLY VOIDS WARRANTY. PROPER MAINTENANCE IS REQUIRED FOR WARRANTY TO BE VALID. IN THE EVENT THAT IT WAS DETERMINED THAT THE WARRANTY CLAIM IS THE RESULT OF MISUSE, ABUSE, IMPROPER MAINTENANCE OR SIMPLY NOT DEFECTIVE OR BEYOND THE WARRANTY PERIOD, WORKSMAN CYCLES OR THE DEALER OR WORKSMAN CYCLES PERFORM THE WORK, THE PARTS WILL BE RETURNED TO YOU AT YOUR EXPENSE OR DISCARDED IF NO REPLY IS RECEIVED WITHIN 2 WEEKS OF NOTICIATION. THE SOLE RESPONSBILITY OF THE MANUFACTURER TO THE TERMS OF THIS WEARRANTY, IF ANY, SHALL BE THE REPAIR AND OR THE MANUFACTURER SHALL NOT BE RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGES OF ANY NATURE, INCLUDING, BUT NOT BY WAY OF LIMITATION, DAMAGES FOR PERSONAL INJURY OR PROPERTY. THIS STATEMENT CONSTITUTES THE EXCLUSIVE EXPRESSION OF WARRANTIES BY THE MANUFACTURER AND IS IN LIEU OF ANY OR ALL OTHER WARRANTIES. SUCH AS EXPRESSED WARRANTIES, IMPLIED WARRANTIES SUCH AS EXPRESSED WARRANTIES, IMPLIED WARRANTIES FOR PURCHASE OF THE PARTS, EXEPT TIRES AND TUBES WHICH ARE NOT WARRANTED. WORKSMAN TRADING CORPORATION IS THE MANUFACTURER. MISUSE OF THE

#