

Handy Recumbent Assembly Procedures Step 1:

Take out all parts in the box: (1) Seat assembly, (2) Back support, (3) Luggage rack, (4) 2 rear wheels, (5) Front frame assembly, (6) Foot rest, (7) Main frame, (8) Front frame fixing plate set, (9) Seat assembly fixing plate set, (10) Luggage rack / rear wheel axle fixing plate set, (11) Wheel skewers and hub covers.



Step 3:

Assemble the luggage rack and rear wheels: Push down the head of the skewer; insert the skewer through the rear hub and into the rear axle, put on the hub cover.



Step 5:

Assemble the seat to the main tube at the desired position, adjust the back support angle and tighten.





Before riding, make sure all bolts are properly tightened.

▲ Important Safety Checklist!

- Check and make sure that all clamps and QR are properly tightened.
- Always wear a helmet and abide by all traffic regulations and courtesies!

Important Maintenance Checklist!

- Important Mainterlance Trecknist:
 1st service inspection after at most 300 km or at latest one months after purchase, repeat every 3 months.
 Parts need lubrication: chain, headset, bearings.
 Parts prohibit lubrication: seatpost, seat tube, adjustable stem, rims.
 Repeat lubrication every half month or after at most 150 km ride.

- Apply lubrication immediately after washing or riding in rainy day.



Step 2:

Join together the front frame, foot rest and main frame: Assemble the foot rest to the front frame, and slide the main frame into the clamp as shown in the picture. Adjust the wheel base to the desired dimension and tighten.





Step 4:

Assemble the back support according to the following picture.



Step 6:

Assemble the hand pedals.







236 Hsia Chuan Tze, Yung An, Hsin Wu, Taoyuan, Taiwan Tel: +886-3-4861231 Fax: +886-3-4861215 Web: http://www.pacific-cycles.com Email: team@pacific-cycles.com