



Assembly Procedures

Step 1:

Unpack the box - one 95% assembled bike, seat / seatpost, 1 rear rack, box contains 1 pair of pedals, rear chassis mounting plate and bolt / washer pack.



Step 2:

Using the small box to fix the frame and put the rear chassis as below, set the chainline to front chainwheel and rear flywheel.




Step 3:

Tighten the mounting plate to the rear chassis with four M5 bolts, in the meantime set appropriate chain tightness.



Step 4:

Tighten the rear carrier with 3 M5 bolts.




Step 5:

Open the spring latch, slide the head tube clamp toward the bottom of the headtube and tighten the wing bolt with your fingers.



Step 6:

Release the seatpost QR lever, swing seatpost backwards and fix with seat stay clamp. Open the QR lever on top of the stem, raise the stem to desired height, close the QR lever. Insert both handlebar ends into the center tube, close the QR levers.



Step 7:

Assemble saddle to the seatpost with M6 allen key. Install the pedals. Turn the right pedal clockwise and the left pedal counterclockwise to tighten.



Step 8:

Adjust the height and alignment of handlebar and seat. You are ready to go!



Note:
Do not raise the seat higher than the minimum insertion mark.

How to fold

Step 1:

Loosen the head tube clamp bolt one turn, slide the head tube clamp to top by pushing the seat backward, latch the head tube to the frame.



Step 2:

Un-lock the seat stays from the seat tube, pull the seat toward the handlebar, open the seat QR lever, lower the seat and turn it side-ways, latch the QR lever to the frame.



Step 3:

Open the stem QR lever, lower the stem and turn the handlebar sideways, close the QR lever.



Step 4:

Fold the pedals.



You are now ready to pull it or carry it!



It's easy to put the Carryall into the trunk too.



- Don'ts!**
- Don't exceed the maximum load limits.
 - Don't carry a person or a pet on the rear carrier.
 - Don't perform stunt riding.
 - Don't jump over curves.
 - Don't raise the handlebar stem beyond the height limit.
 - Don't raise the seat post beyond the height limit.
 - Don't over stress any of the QR levers.
 - Don't ride it off-road.

Important Safety Checklist!

- Check and make sure that all clamps are properly tightened.
 - 1) The handlebars should be tight with no play.
 - 2) The head tube clamp should be fully tightened not allowing rotation or play.
 - 3) The seat stay clamp should be fully tightened (step 4).
 - 4) The seat post clamp should be fully tightened not allowing any rotation or sliding.
- Do not raise the handlebar stem and seat post up beyond the maximum insertion mark.
- Always wear a helmet and abide by all traffic regulations and courtesies!
- Rear carrier max. loading: 10kg / Average speed: 13km/h
- Max. height: 185cm / Max. loading: 80kg

Important Maintenance Checklist!

- 1st service inspection after at most 300 km or at latest one months after purchase, repeat every 3 months.
- Parts need lubrication: chain, headset, bearings.
- Parts prohibit lubrication: seatpost, seat tube, adjustable stem, rims.
- Repeat lubrication every half month or after at most 150 km ride.
- Apply lubrication immediately after washing or riding in rainy day.



236 Hsia Chuan Tze, Yung An,
Hsin Wu, Taoyuan, Taiwan
Tel: +886-3-4861231 Fax: +886-3-4861215
Web: <http://www.pacific-cycles.com>
Email: team@pacific-cycles.com